




**Sound System™**  
Just Plug®

# 3-in-1 Plug Puller Instructions


**JS6983**

### 3-in-1 Plug Puller JS6983

The 3-in-1 Plug Puller makes it easy to remove trigger, power and speaker plugs from Sound System ports! Simply hook, pull and you're done! The 3-in-1 Plug Puller is also compatible with the Just Plug Lighting System.



1. Choose the correct arm (T, P, or S) and hook it onto the corresponding plug's flange. T for trigger, P for power, and S for speaker plugs.




2. Pull the Plug Puller straight out to remove the plug; the P arm also works with Just Plug Lighting System plugs.



**WOODLAND SCENICS®**  
Manufactured by **WOODLAND®**  
PO BOX 98, LINN CREEK, MO 65052  
[woodlandscenics.com](http://woodlandscenics.com)

Distributed by Bachmann Europe.  
13 Moat Way, Barwell, Leicestershire, LE9 8EY. ENGLAND.  
Am Umspannwerk 5, 90518 Altdorf b. Nürnberg. GERMANY.



**WOODLAND SCENICS®**

Manufactured by **WOODLAND®**

PO BOX 98, LINN CREEK, MO 65052

woodlandscenics.com AB3 ©2026 O CO

**Model making product. Not a toy! Not suitable for children under 14 years! / Produit pour le modélisme. Pas un jouet! Pas adapté aux enfants de moins de 14 ans! / Producto para modelismo. No es un juguete! No adecuado para niños menores de 14 años! / Modellbauartikel. Kein Spielzeug! Nicht geeignet für Kinder unter 14!**