

# Assembly Instructions For Z-Scale GMC CCKW 2 ½ ton Cargo Truck



**WARNING: CHOKING HAZARD**  
Keep out of reach of small children!

Note that these ARE NOT TOYS, AND ARE NOT INTENDED FOR USE BY CHILDREN UNDER AGE OF 14. These products are model railroad equipment and accessories intended for use by adults.

**[www.eaelec.com](http://www.eaelec.com)**

Made in Canada

Introduced in April 1943 the canvas covered cab version of the CCKW military truck replaced the earlier metal closed cab type. Over 155,000 of these trucks were produced.

Parts Included in the kit:

- A. 3D printed chassis
- B. 3D printed cab with attached cargo bed
- C. One white star decal



Required to complete the kit:

- Paint - Flat black and flat army olive (Testors #1165).
- Glue - Slow setting CA is best.

Tools Required:

- 1. X-acto Knife with a sharp #11 blade.
- 2. #400 and #600 sandpaper.


The 3D printing process requires a supporting frame during the printing, see below left. The printed part is cut from the frame using flush cutters and this sometimes leaves small bumps on the part. Use a knife with a sharp new blade to cut away the bumps. When trimming bumps off the wheels you should place the wheel on a flat surface as shown below on the right. Putting too much stress on the wheel can cause the axle to break. For bumps on the cab body, sanding is recommended.



After cleaning up the bumps, paint the entire cab-cargo bay flat olive and the chassis flat black. Once these have dried paint the wheel hubs, fuel tank and front bumper olive using a fine brush. Apply a coat of gloss to the top of the hood on the cab where the decal is placed, let dry and then place the decal. After the decal is completely dry, apply dullcoat.

When everything is dry, glue the cab-cargo bay onto the underframe using CA glue. See photo below for cab alignment.

### Final Assembly



When gluing the cab to chassis, front of the cab should extend to red line

