

## Catfish Creek Bridge

## **Bridge Dimensions:** Total Length: 5.4" or 137mm

Roadbed Width: .63" or 16mm

## ASSEMBLY DIRECTIONS

We've included a small sanding pad for the removal of any excess gypsum flash on your bridge and on your wood bridge legs, or piles. Always dry fit pieces

before assembling.

We often use 5minute epoxy but
recently we have been

using Aleene's Turbo Tacky Glue.

Turn the three main bridge sections upside down for a dry fit on a flat surface

and make sure the edges are all flush with each other.
Once sure of the

fit, separate the pieces and apply a

small amount of glue to the areas where the sections touch, then move them back together and let the glue thoroughly dry.



The L-shaped support pieces are

next. One side of these L-shaped supports is longer than the other is; make sure this longer side is on the bottom of the bridge sections (see arrow above).

